

# Soy Wax Candle

## Materials Included

- Soy Wax Pellets (100g)
- Glass Votive Candle Holder
- Candle Wick
- Candle Scent
- Popsicle Stick

## Not Included

- Separate glass container (to melt the wax)
- Microwave or another device to melt the wax.



## Instructions

1. Melt the candle wax pellets in a separate glass container (not included) in a microwave or over hot water until they are completely liquified. If using a microwave, start at one minute and then add in 30 second intervals until the pellets are completely melted.
2. Add the candle scent to the hot wax and stir using the popsicle stick.
3. Dip the metal tab at the bottom of the wick into the melted wax and stick inside the bottom of the candle jar in the center. Use the popsicle stick to push the metal tab into the bottom of the candle jar making sure the wick can stand straight up.
4. Wrap the top part of the wick around the popsicle stick and let it sit on the top of the jar to help the wick stand up straight in the jar.
5. Carefully pour all of the hot wax into the candle jar.
6. Allow several hours for the candle wax to harden.
7. Unwrap the top of the wick from the popsicle stick and trim the wick down to ¼” above the wax.
8. Burn and enjoy!